





SPARE PARTS EXPLODED VIEW  
HEAT PUMPS  
Model  
**NHP32 OUTDOOR UNITS**

R8219353-01 - 10/09/2025

1	4147091	NHP32-036	10-2024	-
2	4147092	NHP32-060	10-2024	-
Col	Reference	Model type	Begin	End









		EN FR	DE ES	NL IT	X
0101	6500834500	PCB CIRCUIT IMPRIME PRINCIPAL	ELEKTROHAUPTPLATINE CIRCUITO PRINCIPAL	PRINTKAART SCHEMA PRINCIPALE	0
0102	6500843100	FAN MOTOR MOTEUR VENTILATEUR	GEBLAESEMOTOR MOTOR VENTILADOR	MOTOR VENTILATOR MOTORE VENTILATORE	0
	6501127800	FAN MOTOR MOTEUR VENTILATEUR	GEBLAESEMOTOR MOTOR VENTILADOR	MOTOR VENTILATOR MOTORE VENTILATORE	0
0103	6500834400	COMPRESSOR COMPRESSEUR	KOMPRESSOR COMPRESOR	COMPRESSOR COMPRESSORE	0
0104	6500837800	LIQUID ACCUMULATOR ACUMULATORE DE LIQUIDE	KAELEMITTELSAMMLER ACUMULADOR DE LIQUÍDO	ACCU VLOEISTOF ACUMULATORE LIQUIDO	0
0105	6500835800	PLATE HEAT EXCAHNGER ECHANGEUR A PLAQUES	PLATTENWAERMETAUSCHER INTERCAMBIADOR DE PLACAS	PLATENWISSELAAR SANITAIR SCAMBIATORE A PIASTRE	0
0106	6500834800	FOUR WAY VALVE VANNE 4 VOIES	4-WEGE-VENTIL VALVULA DE 4 VIAS	4-WEGKLEP VALVOLA 4 VIE	0
0107	6500836500	FOUR WAY VALVE COIL BOBINE DE VANNE 4 VOIES	SPULE FUER 4-WEGE-VENTIL BOBINA PARA VALVULA DE 4 VIAS	SPOEL 4-WEGKLEP BOBINE VALVOLA 4 VIE	0
0108	6500834900	ELECTRONIC EXPANSION VALVE DETENDEUR ELECTRONIQUE	ELEKTRONISCHES UEBERLAUFVENTIL VALVULA EXPANSION ELECTRONICA	ELECTRISCH EXPANSIEVENTIEL VALVOLA ESPANSIONE ELETTRONICA	0
0109	6500834700	EXPANSION VALVE COIL BOBINE	SPULE BOBINA	SPOEL EXPANSIEVENTIEL BOBINA VALVOLA DI ESPANSIONE	0
0110	6500837600	PRESSURE SENSOR 0-20BAR PRESSOSTAT 0-20BAR	DRUCKSCHALTER 0-20BAR PRESOSTATO 0-20BAR	PRESSOSTAAT 0-20BAR PRESSOSTATO 0-20BAR	0
0111	6500837200	HIGH PRESSURE SWITCH PRESSOSTAT ELEVEE PRESSION	DRUCKSCHALTER PRESOSTATO DE ALTA	DRUCKSCHAKELAAR PRESSOSTATO DI ALTA	0
0112	6500837700	PRESSURE SENSOR 0-50BAR PRESSOSTAT 0-50BAR	DRUCKSCHALTER 0-50BAR PRESOSTATO 0-50BAR	PRESSOSTAAT 0-50BAR PRESSOSTATO 0-50BAR	0
0113	6500837500	FLOW SWITCH DEBISTAT	DURCHFLUÁMESSER FLUSOSTATO	WATERDEBIETBEVEILIGING FLUSSOSTATO	0
0115	6500838200	AMBIENT TEMPERATURE SENSOR (TA) AMBIANCE SONDE (TA)	KABELFUEHLER (TA) AMBIENTE SONDA (TA)	VOELER (TA) SENSORE TEMP. AMBIENTE (TA)	0
	6500838700	WATER INLET TEMP. SENSOR (TUI) SONDE TEMP. ENTREE EAU (TUI)	T.SENSOR WASSEREINLASS (TUI) SENSOR T ENTRADA AGUA (TUI)	TEMP.SENSOR WATER INLET (TUI) SENSORE T INGRESSO ACQUA (TUI)	0
	6500838800	WATER OUTLET TEMP. SENSOR (TUO) SONDE TEMP. ORTIE EAU (TUO)	TEMP.SENSOR WASSERAUSLASS (TUO) SENSOR TEMP. SALIDA AGUA (TUO)	TEMP.SENSOR WATER UITLAAT (TUO) SENSORE T USCITA ACQUA (TUO)	0
	6500839100	SUCTION TEMP SENSOR 5K TS SONDE 5K TS	KABELFUEHLER 5K TS SONDA 5K TS	VOELER 5K TS SENSORE 5K TS	0
	6500839200	EVAPORATING COIL TEMP SENSOR (TUP) SONDE (TUP)	KABELFUEHLER (TUP) SONDA (TUP)	VOELER (TUP) SENSORE DI TEMPERATURA (TUP)	0
	6500839300	CONDENSING COIL TEMP SENSOR 5K TP SONDE 5K TP	KABELFUEHLER 5K TP SONDA 5K TP	VOELER 5K TP SENSORE 5K TP	0
	6500839400	DISCHARGE TEMP. SENSOR 50K TD SONDE 50K TD	KABELFUEHLER 50K TD SONDA 50K TD	VOELER 50K TD SENSORE T SCARICO 50K TD	0
0118	6500835000	EVAPORATOR ÉVAPORATEUR	KONDENSATIONSBATTERIE BATERIA CONDENSANTE	CONDENSOR BATTERIA	0
0119	6500836100	REACTOR INDUCTANCE	TRANSFORMATOR REACTOR	REACTOR REATTORE	0
0120	6500837300	RELAY RELAIS	RELAIS RELE	CONTACTOR RELE'	0
0121	6500839800	FAN BLADE VENTILATEUR	LUFTER VENTILADOR	VENTILATOR VENTOLA	0
0124	6500834600	COMPRESSOR HEATING BELT RESISTANCE DU COMPRESSEUR	COMPRESSORWIDERSTAND RESISTENCIA COMPRESOR	VEERSTAND COMPRESSOR RESISTENZA COMPRESSORE	0
0125	6500836700	BOTTOM PLATE HEATER CHAUFFANT PLAQUE INFERIEUR	HEIZELEMENT BODENPLATTE CALENTADOR PLACA INFERIOR	ONDERPLAAT VERWARMINGSELEMENT RESISTENZA FONDO	0
0126	6500836600	WATER TRAY HEATING BELT RESISTANCE RECUP CONDENSATS	WASSERWANNEN-HEIZGÜRTEL CINTURÓN CALENT. BANDEJA AGUA	WATERBAK VERWARMINGSBAND RESISTENZA RACCOGLI CONDENSA	0
0127	6500839600	THERMOSTAT 80-110 THERMOSTAT 80-110	THERMOSTAT 80-110 TERMOSTATO 80-110	THERMOSTAAT 80-110 TERMOSTATO 80-110	0
0128	6500839500	THERMOSTAT 55-60 THERMOSTAT 55-60	THERMOSTAT 55-60 TERMOSTATO 55-60	THERMOSTAAT 55-60 TERMOSTATO 55-60	0
0130	6500841000	AUTOMATIC DISCHARGE VALVE VANNE EVACUATION	ENTLUEFTER VALVULA PURGADORA	ONTLUCHTER VALVOLA DI SFIATO	0
0131	6500888700	TOP PANEL COUVERCLE SUPERIEUR	OBERE ABDECKUNG TAPA SUPERIOR	DEKSEL BOVEN PANNELLO SUPERIORE	0
0132	6500888800	LEFT PILLAR MONTANT GAUCHE	STUETZE HINTEN LINKS MONTANTE (IZQDO)	STEUN LINKS MONTANTE SINISTRO	0
0133	6500888900	BACK PANEL PANNEAU POSTERIEUR	BLECH HINTEN PANEL POSTERIOR	ACHTERPANEEL PANNELLO POSTERIORE	0
0134	6500889000	LATERAL PANEL PANNEAU LATERAL	SEITLICHES PANEL PANEL LATERAL	ZIJPANEEL PANNELLO LATERALE	0
0135	6500889100	GRILL GRILLE	GITTER REJILLA	ROOSTER GRIGLIA	0

		EN	DE	NL	
		FR	ES	IT	
0136	6500889200	FRONT PANEL PANNEAU AVANT	FRONTBLECH PANEL FRONTAL	FRONTPANEEL PANNELLO FRONTALE	0
0137	6500890400	MOTOR MOUNTING BRACKET SUPPORT MOTEUR VENTILATEUR	GEBLAESEMOTORHALTER SOPORTE MOTOR VENTILADOR	STEUN MOTOR VENTILATOR SUPPORTO MOTORE VENTILATORE	0
0201	6500835900	PCB CIRCUIT IMPRIME PRINCIPAL	ELEKTROHAUPTPLATINE CIRCUITO PRINCIPAL	PRINTKAART SCHEDE PRINCIPALE	0
0202	6500835300	FAN MOTOR MOTEUR VENTILATEUR	GEBLAESEMOTOR MOTOR VENTILADOR	MOTOR VENTILATOR MOTORE VENTILATORE	0
	6501127800	FAN MOTOR MOTEUR VENTILATEUR	GEBLAESEMOTOR MOTOR VENTILADOR	MOTOR VENTILATOR MOTORE VENTILATORE	0
0203	6500835400	COMPRESSOR COMPRESSEUR	KOMPRESSOR COMPRESOR	COMPRESSOR COMPRESSORE	0
0204	6500837900	LIQUID ACCUMULATOR ACCUMULATEUR DE LIQUIDE	KAELEMITTELSAMMLER ACUMULADOR DE LIQUÍDO	ACCU VLOEISTOF ACCUMULATORE LIQUIDO	0
0205	6500835100	PLATE HEAT EXCHANGER ECHANGEUR A PLAQUES	PLATTENWAERMETAUSCHER INTERCAMBIADOR DE PLACAS	PLATENWISSELAAR SANITAIR SCAMBIATORE A PIASTRE	0
0206	6500835500	FOUR WAY VALVE VANNE 4 VOIES	4-WEGE-VENTIL VALVULA DE 4 VIAS	4-WEGKLEP VALVOLA 4 VIE	0
0207	6500838900	FOUR WAY VALVE COIL BOBINE DE VANNE 4 VOIES	SPULE FUER 4-WEGE-VENTIL BOBINA PARA VALVULA DE 4 VIAS	SPOEL 4-WEGKLEP BOBINA VALVOLA 4 VIE	0
0208	6500835600	ELECTRONIC EXPANSION VALVE DETENDEUR ELECTRONIQUE	ELEKTRONISCHES UEBERLAUFVENTIL VALVULA EXPANSION ELECTRONICA	ELECTRISCH EXPANSIEVENTIEL VALVOLA ESPANSIONE ELETTRONICA	0
0209	6500836300	EXPANSION VALVE COIL BOBINE DE DETENDEUR	MAGNETVENTIL SPULE BOBINA ELECTROVALVULA	SPOEL EXPANSIEVENTIEL BOBINA VALVOLA DI ESPANSIONE	0
0210	6500837600	PRESSURE SENSOR 0-20BAR PRESSOSTAT 0-20BAR	DRUCKSCHALTER 0-20BAR PRESOSTATO 0-20BAR	PRESSOSTAAT 0-20BAR PRESSOSTATO 0-20BAR	0
0211	6500837400	PRESSURE SWITCH PRESSOSTAT	DRUCKSENSOR SENSOR DE PRESIÓN	PRESSOSTAAT PRESSOSTATO	0
0212	6500837700	PRESSURE SENSOR 0-50BAR PRESSOSTAT 0-50BAR	DRUCKSCHALTER 0-50BAR PRESOSTATO 0-50BAR	PRESSOSTAAT 0-50BAR PRESSOSTATO 0-50BAR	0
0213	6500838400	FLOW SWITCH DEBISTAT	DURCHFLUÄMESSER FLUSSOSTATO	WATERDEBIETBEVEILIGING FLUSSOSTATO	0
0214	6500838000	GAS SEPARATOR SEPARATEUR GAZ	FLUSSIGKEITS-GAS-ABSCHIEDER SEPARADOR GAS	SCHEIDING GAS SEPARATORE GAS	0
0215	6500842400	DISCHARGE TEMP. SENSOR (TD) SONDE TEMP. DECHARGE (TD)	TEMPERATURSENSOR (TD) SENSOR TEMP. DESCARGA (TD)	TEMPERATUUT SENSOR (TD) SENSORE DI TEMPERATURA (TD)	0
	6500842500	SUCTION TEMPERATUR SENSOR (TS) SONDE (TS)	KABELFUEHLER (TS) SONDA (TS)	VOELER (TS) SENSORE DI TEMPERATURA (TS)	0
	6500842600	EVAPORAT. COIL TEMP SENSOR (TUP) SONDE (TUP)	KABELFUEHLER (TUP) SONDA (TUP)	VOELER (TUP) SENSORE T EVAPORATORE (TUP)	0
	6500842700	AMBIENT TEMPERATUR SENSOR (TA) SONDE (TA)	KABELFUEHLER (TA) SONDA (TA)	VOELER (TA) SENSORE AMBIENTE (TA)	0
	6500842800	CONDENSING COIL TEMP SENSOR (TP) SONDE (TP)	KABELFUEHLER (TP) SONDA (TP)	VOELER (TP) SENSORE T CONDENSATORE (TP)	0
	6500842900	WATER INLET TEMP SENSOR (TUI) SONDE TEMP. ENTREE EAU (TUI)	TEMP.SENSOR WASSEREINLASS (TUI) SENSOR TEMP. ENTRADA AGUA (TUI)	TEMP.SENSOR WATER INLET (TUI) SENSORE T INGRESSO ACQUA (TUI)	0
	6500843000	WATER OUTLET TEMP SENSOR (TUO) SONDE TEMP. SORTIE D'EAU (TUO)	TEMP.SENSOR WASSERAUSLASS (TUO) SENSOR TEMP. SALIDA AGUA (TUO)	TEMP.SENSOR WATER UITLAAT (TUO) SENSORE T USCITA ACQUA (TUO)	0
0216	6500838100	SAFETY VALVE SOUPAPE DE SECURITE	SICHERHEITSVENTIL VALVULA DE SEGURIDAD	OVERSTORT VALVOLA DI SICUREZZA	0
0217	6500839000	FUSIBLE PLUG SOUPAPE DE SÉCURITÉ	SICHERHEITSVENTIL VALVULA DE SEGURIDAD	VEILIGHEIDSKLEP VALVOLA DI SICUREZZA	0
0218	6500835700	EVAPORATOR ÉVAPORATEUR	KONDENSATIONSBATTERIE BATERIA CONDENSANTE	CONDENSOR BATTERIA	0
0219	6500840000	AC CONTACTOR AC CONTACTEUR	SCHALTSCHUETZE AC CONTACTOR	AC MAGNEETSCHAKELAAR CONTATTORE AC	0
0220	6500839700	REACTOR REACTEUR	REAKTOR REACTOR	TRANSFORMATOR REATTORE	0
0221	6500839800	FAN BLADE VENTILATEUR	LUFTER VENTILADOR	VENTILATOR VENTOLA	0
0222	6500836200	FILTER BOARD CARTE FILTRE	FILTERPLATINE TARJETA FILTRO	FILTERKAART SCHEDE FILTRO	0
0223	6500836000	DRIVER BOARD DRIVER CIRCUIT IMPRIME	DRIVER ELEKTROHAUPTPLATINE DRIVER CIRCUITO	DRIVER PRINTKAART SCHEDE DRIVER	0
0224	6500839900	COMPRESSOR HEATER RESISTANCE DU COMPRESSEUR	COMPRESSORWIDERSTAND RESISTENCIA COMPRESOR	VEERSTAND COMPRESSOR RESISTENZA COMPRESSORE	0
0225	6500838300	BOTTOM PLATE HEATER CHAUFFANT PLAQUE INFERIEUR	HEIZELEMENT BODENPLATTE CALENTADOR PLACA INFERIOR	ONDERPLAAT VERWARMINGSELEMENT RESISTENZA FONDO	0
0226	6500842300	CONDENSING DRAIN HEATER RESISTANCE RECUP CONDENSATS	KONDENSATIONS-ABLAUFHEIZUNG CALENT.DRENAJE CONDENSACIÓN	CONDENSATIEAFVOERWARMING RESISTENZA RACCOGLI CONDENSA	0
0227	6500839600	THERMOSTAT 80-110 THERMOSTAT 80-110	THERMOSTAT 80-110 TERMOSTATO 80-110	THERMOSTAAT 80-110 TERMOSTATO 80-110	0









---

## IDENTIFICATION PLATE

### SERIAL NUMBER

**16 Characters :**

Fixed reference 21 03 31 20 XX 153101      Sequential number  
 Month of manufacture      Year of manufacture  
 Day of manufacture

**21 Characters :**

Product reference 3675007 XX 07 070 0000315      Sequential number  
 Year of manufacture      Manufacturing day